



VELA Samba

VARIANT:

400/410/500/510/520/530

Manual no. 105563



VELA Samba 510



VELA Samba 530



VELA Samba 520



VELA Samba 400



VELA Samba 410



VELA Samba 500

TABLE OF CONTENTS

1.0. INTRODUCTION	3
1.1. SAFETY	4
1.2. WARRANTY	4
1.3. UNPACKING THE CHAIR	4
1.4. MAINTENANCE	5
1.4.1. Wheels	5
1.4.2. Frame	5
1.4.3. Upholstery	5
1.5. DISPOSAL	5
1.6. USER MANUAL	6
1.6.1. Attaching the backrest	6
1.6.2. Adjustment of seat height with ring	6
1.6.3. Adjustment of seat height with foot ring	6
1.6.4. Adjustment of seat height with lever	6
1.6.5. Adjustment of seat height (Samba 400 & 530)	7
1.6.6. Adjustment of seat tilt (Samba 520)	7
1.6.7. Adjustment of seat tilt (Samba 400 & 530)	7
1.6.8. Adjustment of back height (Samba 520)	7
1.6.9. Adjustment of back tilt (Samba 520)	8

1.0. INTRODUCTION

DEAR CUSTOMER

We would like to thank you for purchasing a VELA Samba. This user manual contain useful information about positioning, operating and maintenance of VELA Samba stools.

Important

Please read this user manual thoroughly and keep it for later use. This user manual must always accompany the chair. The user manual can also be found on VELA's website: www.vela.eu, where you also can find other relevant information about VELA Samba stools.

If you have any questions, please contact VELA's distributor in your country.

VELA reserves the right to make changes to this manual.

VELA

Gøteborgvej 8-12
DK-9200 Aalborg
Denmark
www.vela.eu

GENERAL

1.1. SAFETY

This chair bears the CE mark and conforms to all applicable EU rules. The stool is manufactured by VELA, Vermund Larsen A/S, Goeteborgvej 8-12, 9200 Aalborg SV, Denmark.

VELA Samba is an indoor stool designed for sitting persons.

VELA Samba 400/500/510/520/530 is tested and approved for a maximum user weight of 125 kg.

VELA Samba 410 is tested and approved for a maximum user weight of 95 kg.

1.2. WARRANTY

VELA provides warranty by the laws and regulations which are debt in the country the chair is bought in. The warranty only applies when using original spare parts and accessories. Modification may only be carried out by authorised service technicians.

VELA does not accept responsibility for damage or injury to the product or user, which have arisen due to:

- :: Transportation
- :: Misuse
- :: General wear and tear
- :: Incorrect use
- :: Use of non-original spare parts and accessories

- :: Adjustments carried out by unauthorised service technicians

1.3. UNPACKING THE CHAIR

VELA Samba is supplied in cardboard packaging, developed with consideration for the environment.

If there are any parts missing or transport damage to the chair, please contact your dealer immediately. Do not try to repair any damage or use the chair.

Content of the cardboard packaging:

- :: VELA Samba chair
- :: This user manual

1.4. MAINTENANCE

We recommend your VELA Samba undergoes an annual service to find, for example, defective or worn parts.

1.4.1. WHEELS

VELA recommend that the wheels are checked in regular intervals e.g. to remove possible thread remnants.

1.4.2. FRAME

Clean with water, possibly with a PH neutral soap.

1.4.3. UPHOLSTERY

Fabric: Clean with upholstery cleaners or wipe it with a tightly wrung cloth rinsed in clean water.

Imitation leather: Clean with water or mild soap.

Medical textiles: Clean as described above. Can also be cleaned with disinfectants and alcohol.

Leather: Clean by vacuuming it using a soft dusting brush. Avoid cleaning products.

1.5. DISPOSAL

This product contains recyclable materials such as plastic and metal, etc. As a result, product disposal must be carried out in compliance with local legislation and separately from regular household waste. Correct disposal and recycling contribute to preventing the product from having a negative impact on the environment and people.

1.6. USER MANUAL

Replacement of the gas spring may only be performed by the service support team from your dealer or a skilled technical person.



1.6.1. ATTACHING THE BACKREST

The lever for backrest adjustment (1) must be in open position. Press the locking pin spring (2) and push the backrest arm through the hole. Tighten the lever afterwards.

Note: The backrest arm must be pushed through completely so the pin spring locks the backrest arm. Make sure that the backrest arm cannot be pulled out again.



1.6.2. ADJUSTMENT OF SEAT HEIGHT WITH RING

Adjust the seat height by pushing the ring, which is placed under the seat.



1.6.3. ADJUSTMENT OF SEAT HEIGHT WITH FOOT RING

Adjust the seat height with your foot by pushing the ring, which is placed at the base of the chair.



1.6.4. ADJUSTMENT OF SEAT HEIGHT WITH LEVER

Adjust the seat height by pushing the lever placed at your right hand.



VELA
SAMBA
400 &
530

1.6.5. ADJUSTMENT OF SEAT HEIGHT (SAMBA 400 & 530)

Adjust the seat height by pushing the lever placed at your left hand.



VELA
SAMBA
520

1.6.6. ADJUSTMENT OF SEAT TILT (SAMBA 520)

Adjust the seat tilt by pushing the middle lever placed at your right hand.



VELA
SAMBA
400 &
530

1.6.7. ADJUSTMENT OF SEAT TILT (SAMBA 400 & 530)

Adjust the seat tilt by pushing the lever placed at your right hand.



VELA
SAMBA
520

1.6.8. ADJUSTMENT OF BACK HEIGHT (SAMBA 520)

Adjust the back height by using the lever placed on the back of the chair. Remember to tighten the handle again afterwards.



1.6.9. ADJUSTMENT OF BACK TILT (SAMBA 520)

Adjust the back tilt by pushing the rear lever placed at your right hand.